



Conrad-Johnson Owner's Manual:  
**MF2275 Power Amplifier**

**conrad-johnson** It just sounds right.

*Thank you* for selecting the *MF2275* amplifier to power your audio system. The *MF2275* draws on three decades of research at conrad-johnson into the reproduction of recorded music. The result is a power amplifier with a remarkable ability to recreate the dynamics, textures, tonalities, and ambience of live musical performances. With the *MF2275*, we believe that you will experience the excitement of discovery in hearing more from your favorite recordings than ever before.

At conrad-johnson, we expect our products to be a source of satisfaction and of pride to their owners for many years to come. Accordingly, circuit designs, parts and materials for all conrad-johnson products are selected with a view to maintaining optimal performance over the years. Our reputation for producing among the industry's most reliable components is a natural consequence of this engineering approach.

Although operation of the *MF2275* amplifier is quite straightforward, please take a few minutes to read this manual for useful information on its installation and operation.

In closing, we'd like to welcome you to the family of conrad-johnson owners. We want you to enjoy your conrad-johnson product to the fullest. To this end, our staff stands ready to answer any questions you may have about the function and application of your *MF2275*, and to provide any needed service both during, and after the warranty period. Our goal is to heighten your enjoyment of recorded music.

## **L**imited Warranty For Conrad-Johnson Components

Conrad-Johnson Design, Inc. will provide service under warranty to the original owner on products sold new in the United States for the lesser period of three years from the date of purchase by the original purchaser, or five years from the date of shipment to the authorized conrad-johnson dealer. During the warranty period, conrad-johnson will repair defective units without charge for labor or parts (with the exception of vacuum tubes and batteries).

Exclusions. The following are not covered under this warranty:

- a) Units that have been damaged by misuse, abuse, or accident.
- b) Units that have been modified, altered, or improperly repaired by anyone not specifically authorized by conrad-johnson design, inc.
- c) Units not purchased from an authorized conrad-johnson dealer in the United States for use in the United States.
- d) Normal wear
- e) Incidental or consequential damages are not covered under this warranty. Some states do not allow the exclusion of incidental or consequential damages, so this exclusion may not apply to you.

Obtaining Warranty Service: To obtain warranty service, the unit must be shipped, along with evidence of purchase, in factory packing to conrad-johnson design (or designated service center) with freight and insurance prepaid by the owner. After repair, the unit will be returned with freight and insurance prepaid by conrad-johnson design to any destination in the United States.

All implied warranties, including merchantability and fitness for a particular purpose are limited in duration to the duration of this express warranty. Some states do not allow limitations on the duration of implied warranties so the above limitations may not apply to you.

This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

Conrad-Johnson products purchased outside the United States are covered by warranty terms of the importing distributor in the country in which the product was originally purchased, which may differ from the terms set out herein. Importing distributors are not obligated to provide warranty service for products originally purchased outside their country. Conrad-Johnson will provide warranty service for products outside the United States, but in these cases, the customer must pay all shipping, handling and customs costs both to and from our Service Department.

Questions about this warranty should be addressed to:

Service Department  
conrad-johnson design, inc.  
2800K Dorr Avenue  
Fairfax, VA 22031

The conrad-johnson service department can also be reached by e-mail at [service@conradjohnson.com](mailto:service@conradjohnson.com), by phone at 703-698-8581, or by fax at 703-560-5360.

## **Service**

If your conrad-johnson audio component requires service, repack it using the original box and packing material and ship to the Service Department address above. Boxes and packing materials can be purchased through our service department if you no longer have yours. Include with the unit a note describing the problem you are having in as much detail as possible. It is especially important for our technician to know if the problem is intermittent. If you want an estimate of cost for out of warranty service, be sure to request it in this note. Be aware that requesting an estimate will delay service to your unit, as we will have to contact you for approval before commencing service.

## **Registering The Warranty**

Please return the enclosed card to the factory within 30 days of purchase to register the warranty

# **I**nstallation

As is the case with most power amplifiers, the *MF2275* amplifier dissipates a significant amount of heat. Provision must be made for adequate ventilation. Mount the unit on a flat, hard surface, taking care that the ventilation holes in the bottom are unobstructed. Maintain at least four inches of clearance above the unit, and at least three inches on the sides. The cabinet or shelf should be open at both front and back. For more restricted installations, cooling fans are essential.

All *MF2275* amplifiers sold in the United States are configured for operation on a 60Hz ac power line producing between 108 and 126 volts. Export versions of the *MF2275* will have the correct operating voltage and frequency clearly marked on the back panel of the unit, near the ac power cord. In all cases, the actual line voltage should be within + 5/- 10% of the nominal rated voltage.

## **Electromagnetic Interference (EMI)**

Considerable care has been taken in the design of the *MF2275* to minimize its susceptibility to radio frequency interference and other forms of EMI. Choice of materials, physical layout, grounding practice, and power supply design have all been specified with a view to reducing the impact of electromagnetic fields on the performance of this unit. At the same time, however, our primary goal is the accurate reproduction of recorded music in the normal home environment, and we have elected not to compromise this objective by the application of heavy-handed RFI filters, or by using grounding practices that reduce RFI at the expense of degraded audio performance. We find that the approach we have taken has worked extremely well, resulting in only rare instances of EMI problems which could be treated locally as needed, rather than compromising the performance of our product in the 99.9% of installations where EMI is not a problem.

Care in installation can often avoid EMI induced problems. The following practices should generally be observed in any application, and will be especially important where EMI may be a problem.

Interconnect cables should be kept as short as possible (3 meters or less), and shielded cable should be used (cable which has two

center conductors, and a separate external shield connected at only one end).

Physical location and cable “dress” can be an important factor in minimizing hum pickup. The installation should situate the preamplifier well away from the power amplifier, and power (ac mains) cords should be dressed to remain at least 4" (100mm) away from input/output cables.

## **C**onnection

**INPUT:** Connect the preamplifier to your *MF2275* amplifier at the RCA type connectors located on the back of the amplifier.

**OUTPUT:** Five-way binding posts are provided for connection of your loudspeakers, with correct spacing to accept a standard "double banana" plug. They will also accept spade lugs, bare wire, or pin connectors.

The two channels should be connected in correct "relative phase". This means that when the same signal is applied to both channels, the right and left channels speaker diaphragms will move synchronously - in and out together. Terminals on speakers are usually coded - one designated "C", "ground", "-" or black, the other designated "+" or red. "In phase" connection of the speakers can normally be achieved by taking care to connect the wire from the "+" amplifier terminal to the red or "+" coded terminal on each speaker, and connecting the "-" terminal to the black or "-" coded terminal on each speaker. In phase connection of the speakers can be readily ascertained by ear. Listen to a recording of a solo vocalist (use a mono recording if available). With the speakers in phase the voice should be clearly focused between the two speakers. With the speakers connected out of phase, the voice will be diffused, with no identifiable source. Relative phase may be reversed by switching the "+" and "-" leads at one speaker only.

# **G**etting The Most From Your MF2275 Amplifier

In a system of commensurate high quality components, the Conrad-Johnson MF2275 amplifier offers an unparalleled level of sophistication and refinement in music reproduction. To get the best performance out of any audio system, there are a number of important details that must be attended to.

## **Absolute Phase**

Musical notes are heard through the ear's response to waves of alternating rise and fall of air pressure. Musical transients are almost exclusively positive: that is, the initial effect is a rise in pressure. The ear is capable of distinguishing these positive transients from the musically unnatural alternative of a negative transient (an initial fall in air pressure). In terms of your stereo system, these transients are created by your loudspeakers. If the speakers respond to musical transients by first moving out, they are creating a rise in pressure, and the system is said to be phase correct. If they respond by moving in, they create a fall in pressure and the system is said to be phase inverting. Each component in the stereo system either preserves the phase of the incoming signal, and is said to be phase correct, or inverts the phase and is said to be phase inverting. It is unimportant whether an individual component is phase correct or phase inverting, as long as the system as a whole is phase correct. This will be the case if the number of phase inversions is even (or zero).

The MF2275 is phase correct (non-inverting). If your system has an odd number of inversions, (for example, if you have a phase inverting preamplifier) then you must add one phase inversion. This is conveniently done by reversing the positive and negative connections to your speakers (be sure to reverse both channels). If you are not sure about the phase of every piece in your system, you can establish correct absolute phase by careful listening. When the system is in correct phase, transients will be noticeably cleaner and more sharply defined. The effect is especially apparent on plucked string sounds. A final warning - not all recordings are phase correct (including some "audiophile" recordings), so listen to several before concluding your investigation of absolute phase.

## The Importance Of Wires

Interconnect and speaker wires are an important element in your stereo system. Interconnects are available which will permit a reference quality system to blossom and fulfill its promise of musical reality. Others will strangle the system to the point where it becomes little better than average. To complicate matters, our experience suggests that the choice of interconnects will be system dependent - those that are top ranked on one system may be a poor choice for a different system. Consult your Conrad-Johnson dealer for recommendations for your specific system.

## Performance Tip

Warm up the *MF2275* before listening: The sonic performance of the *MF2275* improves noticeably as the unit warms up. The midrange becomes more lucid, the highs smoother, and the soundstage expands. The warm up period can be expected to last about fifteen minutes.

**Questions:** If you have questions about the installation or function of your *MF2275* do not hesitate to call Customer Service at (703) 698-8581.

# **S**pecifications

**Power:** 135 watts per channel RMS both channels driven into 8 ohms from 20Hz to 20KHz at no more than 1.0% total harmonic distortion or intermodulation distortion.

**Sensitivity:** 1.35 V rms to rated power

**Frequency Response:** 20Hz to 20 kHz +0/-3 dB

**Hum and Noise:** 100 dB below rated power output

**Phase:** phase correct

**Input Impedance:** 100 kOhms

## **Mechanical**

**Dimensions:** 14.625"D x 19"W x 4.875"H

**Net Weight:** 33 lb. net

## **Fuses**

There are 5 fuses in the MF2275. One is the ac power line (mains) fuse. It is located in the IEC power cord receptacle. The other four fuses are in the DC power supplies for the output stages one for the positive (B+) and one for the negative (B-) supply to each channel. These B+/B- fuses are located on the top of the main printed circuit board. Be sure to disconnect the amplifier from the ac mains power (wall outlet) before removing the top cover.

**Never replace a fuse with a value or type different from that originally supplied by the factory.** Correct values and types are listed below. In the event of a fuse blowing repeatedly, contact your dealer or the conrad-johnson service department.

AC Mains Fuse: 5x20mm T-Type:  
6.3 amp if configured for 100 or 120V  
3.15 amp if configured for 220 or 240V

B+/B- Fuses: 3AG 4 Amp, fast blow